MORTISE LOCK DRILLING TEMPLATE

CENTERLINE OF DOOR

HEIGHT LINE FROM FLOOR
38" - 41" or a pleasing distance

CENTERLINE OF DOOR

Faceplate dimensions: 7/8" x 6"

Drill
6 holes
5/8" dia. (0.625")
to 3 1/4" depth
(3/4" apart on ₵)

Remove
this area
to 1/2" depth

Remove
this area
to 3 1/4" depth

Remove
this area
to approx.
1/8" depth

Guide hole
for screw
3/32" dia.
(.093")

LOCK & FACEPLATE

Fold dotted line along door edge to mark spindle hole and key hole when fitting

EDGE OF DOOR TO ₵ OF KNOB 2 5/16"

3/4" dia.
(0.750")

Exactly 2 1/4"

Drill
2 holes
3/8" dia.
(0.375")

Exactly 1/2"

TEMPLATE USE:

TEMPLATE

DOOR FACE

HINGES

Do not scale this drawing.
Dimensions may vary slightly.

Drill
5 holes
9/16" dia.
(0.5625")

Remove
this area
to 5/8" depth

Guide hole
for screw
3/32" dia.
(.093")

STRIKE

For size accuracy please measure this line. It should be 1" exactly.