

INSTRUCTIONS

- 1) IDENTIFY DOOR WITH SURFACE VERTICAL ROD EXIT DEVICE AND MARK DEVICE CENTERLINE IF IT IS NOT ALREADY MARKED ON THE DOOR.
- 2) USE EXIT DEVICE CENTERLINE AND DIMENSIONS SHOWN ON THIS PAGE TO MARK AND DRILL HOLES.
- 3) INSTALL DOUBLE DOOR STRIKE WITH PROVIDED SCREWS.

NOTES

- STANDARD DOOR GAP IS 3/16" [4.8] ±1/16" [1.6] 4921 DOUBLE DOOR STRIKE IS NOT FIRE DOOR RATED.
- 3. USE A COORDINATOR ON INACTIVE DOOR.



PROPRIETARY & CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE COMPANIES, ANY REPRODUCTION INPART OR AS A MULCISION R° INPART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF HAGER COMPANIES IS PROHIBITED. OF TEI

HAGER RESERVES THE RIMAKE CHAN WITHO

IGHT TO F DESIGN		
NGES OUT NOTICE. HAGER	MATERIAL Material <not specified=""></not>	
NEERING AT -325-9995 THE LATEST	FINISH -	
ION DATE MPLATE.	DO NOT SCALE DRAWING	

DRAWN	TJS	8/7/07		
ENG. APPR.	-	-		
Q.A.				
TOLERANCES: FRACTIONAL: ±0.015" ANGULAR: MACH: ± 1° BEND: ±1° TWO PLACE DECIMAL: ±0.01" THREE PLACE DECIMAL: ±0.004"				

4921
4500 DOUBLE DOOR STRIKE INSTRUCTIONS & TEMPLATE

SIZE	DWG.	NO. T-ED00104		REV.
SCALE:1:24		WEIGHT: 442.40	SHEET 1	OF 1