Architectural Door Accessories

Rockwood 471 Door Stop

NOT TO SCALE

Template $1^{1}/_{4}$ " $\Gamma_{-}A^{-}$ ⁵/₈" Wire Brad $-\frac{1}{4}''$ Effective date: January 1, 2017 Supercedes: All Previous $1^{1}/8''$ NOTE: ASSA ABLOY reserves ⁷/8" the right to make product changes and is not responsible for obsolete template errors. To ensure your template is current, please TPR Bumper visit our website at 3" www.rockwoodmfg.com or 17/32" call us at 800-458-2424 rad. 3/16" $2^{1}/_{2}$ " 1 Hole for #8 Screw ⁵/₁₆"–18 x 1" dp. (#471 only) \bigcirc (#471 only) MATERIAL: Cast Brass with DuraFlex Bumper **FASTENERS NOTE:** 1 ea. $\frac{5}{16}$ "-18 x 1 $\frac{3}{4}$ " Stud, Lead Anchor; #8 x ³/₄" Oval Head Sheet Metal Screws, Plastic Anchor 3 Holes for #12 Screws (#470 only) ¹⁵/₁₆"

300 Main Street Rockwood, Pennsylvania 15557 P: 800.458.2424 | F: 800.922.9212 www.rockwoodmfg.com | orders.rockwood@assaabloy.com

Copyright © 2017, Rockwood Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Rockwood Manufacturing Company is prohibited. The global leader in door opening solutions

