



Installation Instructions

Important: Please read these instructions before starting work.

1. Check that there are no buried pipes or cables before drilling and holes. Take extreme care when using electrical equipment near water.
2. Do not fix accessories onto newly painted surfaces as chemical reactions could cause discoloration to the products. (Please refer to the manufactures instructions.)
3. We recommend the use of a specialized drill bit when fixing accessories to tiled areas.

Supplied Mounting hardware:

Allen key, mounting posts, decorative posts, screws and wall plugs.

Mounting Instructions:

1. Establish the position for the accessories, making sure there is sufficient room.
2. Hold the backplate in the required position onto the wall and mark holes through with a pencil. Ensuring the marks are horizontal by use of a carpenter's level.
3. Drill holes to a depth of 1" inch using a ¼" inch drill bit and insert the wall plugs so they are flush with the wall.
4. Fix the backplate onto the wall by inserting the supplied screws through the mounting posts then through the backplate into the wall plugs and tighten.
5. Position the decorative posts onto the mounting post, making sure that the set screw points directly downward before tightening with Allen key.

Care Instructions:

We recommend regular cleaning with a mild soap and dried with a soft cloth. The use of abrasive cleaners or bleaches will damage the finish.

If further assistance is required, please contact Customer Service at 1-888-825-7266 (9am-5pm EST)