

EXTENSION ROD/ADJUSTABLE EXTENSION ROD

To calculate extension rod length needed, use the formula below based on style holder being used.

Flush mount: Measure distance from door to wall when held at desired opening. Subtract 3" (76 mm) to obtain extension rod length needed.

Recessed mount: Measure distance from door to wall when held at desired opening. Subtract 2-3/8" (60 mm) to obtain extension rod length needed.

Surface mount: Measure distance from door to wall when held at desired opening. Subtract 4-5/8" (117 mm) to obtain extension rod length needed.

See example below using flush mount.

