


CR25LM/DM



IMPORTANT:

It is highly recommended that you install the **cam/prong driver** and **lock cylinder** into the lock body and cycle to the locked position **before** assembling cam, cam shifter and stop pin onto the back of the lock.






Lock diameter is 1-1/8". Drilled hole should be slightly larger.

Title Installation instructions for CR25LM/DM series cam lock					OLYMPUS
Series	Barrel Length	Bolt type	Mounting	Revision Date	Ŭ •
CR25	1-7/16"	Cam lock	Surface	09/2014	LOCK, INC.

Page 2





Installation instructions for CR25LM/DM series cabinet lock

Page 3

LOCK, INC


CR25LM/DM Assembled with vertical long cam 720-3-2 or extra long 3" cam 720-3-4 BU AU IMPORTANT! If your cam has a brass pin on the 3 3 2 1 bottom of the cam use these instructions, otherwise see page 2. 720-KR 720-CDDM (A Side) 720-CDDM (B Side) 720-CDLM lost motion cam shifter key retaining drawer key retaining door cam shifter key retaining door cam shifter (non-key-retaining) cam shifter L L LH Door or OCKED **RH Door** 0 C K Drawer or Drawer Е D Stop pin Stop pin-Key removable Key removable in in locked or locked or unlocked 1 1 unlocked position. position. LH Door **RH** Door Key Key Retaining Retaining Stop pin Stop pin -LOCKED LOCKED Key removable Key removable in locked in locked position only. position only. L 0 C K E 0 C K Drawer Drawer Key Key Retaining Retaining Е D D Stop pin Stop pin-Key removable Key removable in locked 2 in locked position only. position only. **OLYMPUS**

Installation instructions for CR25LM/DM series cabinet lock


CR25LM/DM

Assembled with short cam 720-3-1

Page 4



Assembled with inverted long cam 720-3-3 or 720-3-5



Installation instructions for CR25LM/DM series cabinet lock