

Installation Instructions


DCP

Typical Installation





Available Cams:



Straight Cams:

Part No.	Dim. A	
DCP-58	5/8"	
DCP-SC**	7/8"	
DCP-LC**	1-1/4"	
DCP-LC-112	1-1/2"	
DCP-LC-134	1-3/4"	
DCP-LC-225	2-1/4"	
DCP-LC-250	2-1/2"	

^{**}These cams ship standard with each lock

0


 \bigcirc

DCNP-500-ARP anti-rotation plate

install on inside of

044		
Offcet	-91	110

Part No.	Dim. A	Dim. B
DCP-1-14	1"	1/4"
DCP-LBC	1-1/4"	1/4"
DCP-118-18	1-1/8"	1/8"
DCP-LBC-138	1-3/8"	3/8"
DCP-LBC-178	1-7/8"	1/2"
DCP-112-14	1-1/2"	1/4"
DCP-114-18	1-1/4"	1/8"
DCP-114-38	1-1/4"	3/8"
DCP-118-18	1-1/8"	1/8"
DCP-1-14	1"	1/4"
DCP-2-18	2"	1/8"



Title Installation instructions for DCP series padlockable cam lock							
mistaliation instructions for Der series padioekable talli lock							
Series	Barrel Length	Bolt type	Mounting	Revision Date			
DCP	See Chart	Cam Lock	Surface	07 / 2011			

07/2011 See Chart Cam Lock Surface

