


Kitchen sink - Series- various
 Strainer remote control with turning knob - platinum matte
 Article number: 10 711 970-06

Spare parts list



| Number | Item Number | Designation | Number of units |
|--------|--------------------|--|-----------------|
| 1 | 09 20 97 030-06 | Handle - platinum matte | 1 |
| 2 | 09 12 12 002 90 | Upper part white - | 1 |
| 3 | 09 27 87 007-06 | Escutcheon - platinum matte | 1 |
| 4 | 09 14 10 043 90 | Washer - | 1 |
| 5 | 09 14 10 042 90 | Washer - | 1 |
| 6 | 09 29 06 087-06 | spindle | 1 |
| 7 | 04 30 01 029 00 90 | Wall connection - | 1 |
| 8 | 09 24 03 175 90 | Wall connection - | 1 |
| 9 | 09 11 10 073-07 | Wall connection - Rough nickel-plated | 1 |
| 10 | 09 11 10 074-07 | Wall connection - Rough nickel-plated | 1 |
| 11 | 09 11 10 079-07 | Wall connection - Rough nickel-plated | 1 |
| 12 | 09 30 11 087 90 | Washer - | 1 |
| 13 | 09 23 30 024-07 | Mounting bracket - Rough nickel-plated | 1 |