


Kitchen sink - Lot

Two-hole mixer with cover plate - polished chrome

Article number: 32 843 680-00 0010

Spare parts list



Number	Item Number	Designation	Number of units
1	90 11 06 188 08-00	Outlet - polished chrome	1
2	90 23 01 029 04-00	Aerator - polished chrome	1
3	04 23 10 044 01 90	Mounting bracket -	1
4	90 27 78 024 00-00	Cover - polished chrome	1
5	09 30 30 057 90	Mounting bracket -	1
6	09 30 11 028 90	Washer -	1
7	09 14 10 077 90	Washer -	1
8	04 24 04 166 10 90	Nipple -	1
9	09 14 20 002 90	Washer -	1
10	90 20 78 040 00-00	Lever - polished chrome	1
11	09 24 04 142-00	Mounting bracket - polished chrome	1
12	09 14 10 037 90	Washer -	1
13	04 28 10 148 00 90	EHM cartridge -	1
14	90 15 05 061 00 90	EHM cartridge -	1
15	09 30 01 100 10 90	Wall connection -	1
16	04 30 11 038 02 90	Mounting bracket -	1
17	09 31 11 011 90	Mounting bracket -	1
18	09 18 40 079 90	Hood / sleeve -	1
19	04 30 04 045 00 90	Flexible supply line 3/8"	2
20	04 30 04 019 00 90	Flexible supply line -	1