
## 4930 GLASS BEAD SHIM INSTALLATION INSTRUCTIONS FOR USE WITH 4500 SERIES EXIT DEVICES




## FIGURE 1

\* ORIENT THE LATCH SHIMS SO THE LONGER END IS NEAR THE LATCH BOLT.

## **INSTALLATION INSTRUCTIONS:**

- FOLLOW EXIT DEVICE INSTALLATION INSTRUCTIONS TO PREPARE DOOR AND DEVICE FOR MOUNTING.
- INSERT SHIMS BETWEEN THE EXIT DEVICE AND THE DOOR.
  - SHIMS ARE NON-HANDED AND CAN BE USED FOR RH OR LH APPLICATIONS.
  - 2. SURFACE VERTICAL ROD LATCH SHIMS HAVE ONE END THAT IS LONGER, ORIENTATION IS CRITICAL FOR PROPER INSTALLATION (SEE ILLUSTRATION).
  - 3. RIM EXIT DEVICE (NOT SHOWN) WILL NOT REQUIRE ROD GUIDE OR LATCH SHIMS.
- SECURE EXIT DEVICE WITH PROVIDED SCREWS, SEE FASTENER LIST BELOW FOR PROPER FASTENER LOCATION.



(SURFACE VERTICAL ROD SHOWN)

## **FASNTENER LIST (SEE FIGURE 1):**

A. METAL: 1/4"-20 X 1" BUTTON HEAD MACHINE SCREW. WOOD: #12 X 1-1/2" BUTTON HEAD WOOD SCREW.

B. METAL: 1/4"-20 X 1" FLAT HEAD MACHINE SCREW. WOOD: #12 X 1-1/2" FLAT HEAD WOOD SCREW.

C. METAL: #10-24 X 1" BUTTON HEAD MACHINE SCREW. WOOD: #10 X 1-1/4" BUTTON HEAD WOOD SCREW.



DRAWING NO: I-ED00140 REV: 03 SHEET 1 OF 1