


Architectural Door Accessories

ASSA ABLOY

Rockwood OH200 Series Concealed Door Stops and Holders


The global leader in
door opening solutions

NOT TO SCALE




INSTALLATION INSTRUCTIONS

1. Select proper dimensions from chart on opposite side of page.
NOTE: Add $\frac{3}{8}$ " to "A" dimension for dead stop.
2. Locate "B" dimension on frame and mortise $\frac{3}{16}$ " deep for jamb bracket as shown.
3. Locate "A" and "F" dimensions on centerline of door and mortise $\frac{13}{16}$ " wide x $\frac{7}{8}$ " deep for channel. $\frac{1}{16}$ " head clearance shown. Coordinate the arm and rail cutout dimensions if head clearance varies.
4. Locate "C" and "E" dimensions on top of door and mortise $\frac{1}{4}$ " deep as shown for arm clearance.
5. Install door stop or holder with screws provided.



CAUTION:

Note location of swing clear hinge centerline to determine "A", "B" and "C" dimensions.



FASTENERS NOTE:

Jamb: #12-24 x $\frac{1}{2}$ " Flat Head Machine Screws
or #12 x $\frac{1}{2}$ " Flat Head Wood Screws
Door: #12-24 x $\frac{1}{2}$ " Flat Head Machine Screws
or #12 x $\frac{1}{2}$ " Flat Head Wood Screws


NOTES:

- All hollow metal frames are to be provided with $\frac{3}{16}$ " min. thickness x 12" min. length reinforcement plates.
- All hollow metal doors are to be properly reinforced as shown.
- Adjustments are necessary if dead stop is required.
- A, B, and C dimensions are measured from center line of pivot, not edge of door.
- Reversible, non-handed.

Template T-OH200

Effective date: January 1, 2017
Supersedes: All Previous


NOTE: ASSA ABLOY reserves the right to make product changes and is not responsible for obsolete template errors. To ensure your template is current, please visit our website at www.rockwoodmfg.com or call us at 800-458-2424



Rockwood OH200 Series Concealed Door Stops and Holders (cont.)

When using center hung pivots, check pivot manufacturer's compatibility prior to specifying.

1. See other side for installation instructions.
2. Select proper dimensions noted below.
3. Add $\frac{5}{8}$ " to "A" dimension for dead stop.
4. All dimensions given in inches.



	Device Number		Door Opening	A	B	C	E	F
	Stop	Multi						
1 $\frac{3}{4}$ - 2 $\frac{3}{4}$ Butts & 3 $\frac{1}{4}$ Offset Pivot	201S	201M	*18 - 24	1 $\frac{3}{16}$	3 $\frac{11}{16}$	0	15 $\frac{5}{16}$	15 $\frac{7}{8}$
	202S	202M	24 $\frac{1}{16}$ - 30	4	4 $\frac{3}{8}$	2 $\frac{9}{16}$	16 $\frac{9}{16}$	17 $\frac{1}{16}$
	203S	203M	30 $\frac{1}{16}$ - 36	6 $\frac{3}{4}$	5 $\frac{9}{16}$	4 $\frac{11}{16}$	19	18 $\frac{13}{16}$
	204S	204M	36 $\frac{1}{16}$ - 42	9 $\frac{7}{8}$	7 $\frac{1}{4}$	6 $\frac{3}{8}$	23	21 $\frac{1}{4}$
	205S	205M	42 $\frac{1}{16}$ - 48	13 $\frac{13}{16}$	8 $\frac{1}{2}$	7 $\frac{5}{8}$	27 $\frac{1}{2}$	23 $\frac{1}{16}$

	Device Number		Door Opening	A	B	C	E	F
	Stop	Multi						
Center Hung	-	-	-	-	-	-	-	-
	202S	202M	27 - 32	5 $\frac{7}{16}$	6 $\frac{1}{8}$	5 $\frac{1}{4}$	15 $\frac{5}{8}$	17 $\frac{1}{16}$
	203S	203M	32 $\frac{1}{16}$ - 38 $\frac{1}{2}$	7 $\frac{3}{16}$	6	5 $\frac{9}{32}$	19	18 $\frac{13}{16}$
	204S	204M	38 $\frac{9}{16}$ - 45	10 $\frac{5}{16}$	7 $\frac{11}{16}$	6 $\frac{13}{16}$	23	21 $\frac{1}{4}$
	205S	205M	45 $\frac{1}{16}$ - 48	14 $\frac{1}{4}$	8 $\frac{15}{16}$	8 $\frac{1}{16}$	27 $\frac{1}{2}$	23 $\frac{1}{16}$

TO SELECT DEGREE OF STOP

1. With a $\frac{3}{16}$ hex key wrench, loosen the set screw in the shock block.
2. Open door to desired degree of opening.
3. Slide shock block and spring until the spring touches slider cam.
4. Tighten set screw.
5. Verify door opening position and re-adjust, as needed.

* Butt mounting only. Reversible, non-handed.